HƯỚNG DẪN CẤU HÌNH RUCKUS SMARTZONE

1) **Đăng ký AP vào controller**

   Login vào console AP thực hiện lệnh

   set scg ip ip_of_controller

2) **Tạo Group AP(Zone)**





3) **Tạo Template**





4) Cấu hình SSID







5) Cấu hình link Splashpage



Redirected unauthenticated user : http://sp.jwifi.vn/ruckus

6) Cấu hình Walled garden



Thêm vào danh sách Walled garden

*.jwifi.vn

*.zalopay.vn

sbgateway.zalopay.vn
gateway.zalopay.vn
*.zalopay.com.vn
*.momo.vn
ebanking.dongabank.com.vn
vietcombank.com.vn
payment.napas.com.vn
www.google-analytics.l.google.com
www.google-analytics.com
google-analytics.com
tagmanager.google.com
www.googletagmanager.com
www-googletagmanager.l.google.com
www3.l.google.com
*.facebook.com
*.facebook.net
*.userreport.com
*.fbcdn.net
scontent.fsgn2-4.fna.fbcdn.net
*.akamaihd.net

7) Cấu hình Radius





Primary Server :

Host : 45.118.139.111 Port 1812 Shared Secrect : testing123

Secondary Server :

Host : 45.118.139.112 Port 1812 Shared Secrect : testing123



8) Import Zone template vào Group

Trong phần Access Point chọn Zone vào More chọn Import Zone Template


Virtual SmartZone High Scale
vszcluster
2021-05-17 14:11:10
default
admin
Access Points (2)
1 online 0 flagged 1 offline
View Mode: List Group Mesh Map Zone
More
Configure
Move
Delete
More
search table
System 1
Test
VNTT 1
BinhDuong
TonDucThang 1
default 1
Staging Zone
Clients
Latency (2.4G)
Import Zone Template
* Select a Zone template:
Zone_Template
OK
Cancel
1 records
General
Configuration
Health
Traffic
Alarm
Event
Clients
Wired Clients
GPS Location